TORNADO INDUSTRIES
7401 W. LAWRENCE AVENUE
CHICAGO, IL 60706
708) 867-5100 FAX (708) 867-6968
www.tornadovac.com

Tornado® Operations & Maintenance Manual

MODEL NO.
99785 BR 33/30

L9726 ©2007 Tornado Industries All rights reserved.

Table of Contents

PRODUCT SPECIFICATIONS 1
WARRANTY 2
LEGEND PANEL OF CONTROLS 3
LEGEND MACHINE 3
INTRODUCTORY COMMENT 4
GENERAL RULES 4
SYMBOLS 4
BEFORE USE 5
Handling of the packed machine 5
Unpacking of the machine 5
Access to the battery compartment 5
Battery installation and setting of the battery type 5
Assembling the rollbar 5
Battery charger 5
Battery recharging 5
Battery disposal 5
Connecting battery connector and switching on the machine 5
Battery charge level indicator 6
Hour meter 6
Squeegee assembly 6
Squeegee adjustment 6
Adjustment height side rubbers 6
Brush assembly and disassembly 6
FLOOR CLEANING 7
Recovery tank 7
Detergent solution tank 7
STARTING OF THE MACHINE 7
Forward and backward movement 7
Horn 7
Working brake 7
Emergency-parking brake 8
Automatic squeegee lift when going backwards 8
Working in automatic mode 8
Working in manual mode 8
Flow adjustment of detergent solution 9
Brush pressure adjustment 9
Electric protection 9
Overflow device 9
STOPPING THE MACHINE AFTER CLEANING OPERATION 9
DAILY MAINTENANCE 9
Recovery tank emptying and cleaning 9
Emptying and cleaning the collection box 9
Suction filter cleaning 10
Brush cleaning 10
Squeegee cleaning 10
WEEKLY MAINTENANCE 10
Rear squeegee rubber check 10
Check of the side rubbers 10
Squeegee hose cleaning 10
Cleaning of the solution tank and of the outer filter 10
TWO-MONTH MAINTENANCE 11
Front squeegee rubber check 11
SIX-MONTH MAINTENANCE 11
Cleaning the inner filter solution tank 11
Check the brake 11
TROUBLESHOOTING GUIDE 11
The vacuum motor does not work 11
The brush motor does not work 11
The traction motor does not work 11
The water does not come down onto the brushes or is insufficient 11
The machine does not clean properly 11
The squeegee does not dry properly 11
Excessive foam production 11
PROGRAMMED MAINTENANCE 12

PRODUCT SPECIFICATIONS	
Model	BR 33/30
Machine Dimensions	
L X W X H	65" X 36" X 51"
Net Weight	739 lbs.
Solution / Recovery Tank	30 / 32 gal.
Squeegee Width	45"
Design Characters	
Tank Construction	Polyethylene
Cleaning System	
Brush Type	Cylindrical
Brush Width	33"
Brush RPM	785
Brush Pressure	176 lbs. (max)
Cleaning Path	33"
Productivity	
Cleaning Rate (Sq. Ft Per Hour)	14,851
Motors	
Vacuum Motor	.8 hp
Brush Motor	0.9 hp
Sound Level	70 dB
Battery	
Voltage	36
Amps	240

Long-term buyer protection warranties

Tornado Standard Warranty Program*

Warranties do not cover components subject to normal wear or abuse and misuse, and have other limitations not specified here. For full details, contact your Authorized Tornado Distributor, Service Center, or the Tornado Service Department.

Tornado sales and services representatives are not authorized to waive or alter the terms of this warranty, or to increase the obligations of Tornado under the warranty.

10 Years:
All plastic tanks and rotationally-molded bodies

2 Year:
On all Tornado components
****except as shown below***

1 Year:
Labor on all Tornado cleaning equipment
****except as shown below***

1 Year:
Warranty on batteries and chargers, one year, pro-rated
All battery warranties are handled by the battery manufacturer, please call customer service for more information.

Thank you for choosing Tornado products. We are proud to offer the most complete line of commercial and industrial cleaning equipment in the industry. Our reputation for quality, innovation and durability is unsurpassed.

* Effective January 1st, 2007. Terms subject to change without notice.
1)Windshear™ Blower-Dryers, Insulation Blowers, CK LW 13/1, CK 14/1, CV 30, CV 38, Pro PAC Vacs, PV 6 Back Pack Duo-Upright Carpetkeepers™, and all chargers are warranted for 1 (one) year for both parts and labor.
2)Warranties on the EB30 are 90 days (batteries, charger, parts, accessories)
3)Warranties on all riding sweepers including the ICC1, KM 100/100 R, KMR 1250, and KMR 1700 are 24 months parts/6 months labor OR 1000 hours of operation, whichever comes first. Warranties on all riding scrubbers inluding the 75/140 & 90/140 are 24 months parts/12 months labor OR 1,000 hours of operation whichever comes first.
4)All non-wear item parts purchased after warranty expiration are warranted for 90 days.
5)Warranty starts from the date of sale to the consumer 6 months after dealer purchased the unit from Tornado, whichever comes first.

Note: Tornado, The Latest Dirt, Floorkeeper, Carpetkeeper, Carpetrimser, Carpetrimser/Dryer, Headmaster, Taskforce, PAC-VAC, T-Lite, Glazer, Windshear, Max-Vac, CV 30, CV 38, and Dot-Mop are trademarks of Tornado Industries.

1-800-VACUUMS
Chicago area: (708) 867-5100
Fax: (708) 867-6968
7401 W. Lawrence Avenue
Chicago, IL 60706

Form# F2665-Rev 4/01/07 IH
© 2007. All rights reserved.

LEGEND PANEL OF CONTROLS

1. DISPLAY
2. SIGNAL LAMP: PARKING BRAKE
3. AUTOMATIC/MANUAL SELECTOR
4. UP/DOWN SQUEEGEE PUSH BUTTON
5. SUCTION MOTOR SWITCH
6. SIGNAL LAMP: UP/DOWN SQUEEGEE
7. SIGNAL LAMP: SUCTION MOTOR ON
8. BRUSH PRESSURE ADJUSTMENT KNOB
9. PUSH BUTTON VISUALIZATION HOUR METER (DISPLAY)
10. PUSH BUTTON VISUALIZATION BRUSH PRESSURE SET (DISPLAY)
11. SELECTOR: FORWARDS/BACKWARDS
12. SELECTOR: SPEED
13. UP/DOWN BRUSHES PUSH BUTTON
14. WATER OPENING (SOLENOID VALVE) SWITCH
15. SIGNAL LAMP: UP/DOWN BRUSHES
16. SIGNAL LAMP: WATER OPEN (SOLENOID VALVE)
17. SIGNAL LAMP: STARTING BRUSHES ROTATION
18. KEY SWITCH
19. HORN PUSH BUTTON
20. KNOB FOR SOLUTION VALVE



LEGEND MACHINE

1. RECOVERY TANK
2. SOLUTION TANK
3. SEAT
4. DRIVE WHEEL
5. SCREW CAP FOR INLET DETERGENT SOLUTION
6. BLINKING LIGHT
7. ROLLBAR
8. SUCTION HOSE
9. SUCTION COVER
10. SQUEEGEE HOSE
11. SUCTION COVER BLOCKING LEVERS
12. RECOVERY TANK EXHAUST HOSE PLUG
13. RECOVERY TANK EXHAUST HOSE
14. SQUEEGEE ASSEMBLY
15. PANEL CONTROLS
16. BLOCK/RELEASE PARKING BRAKE LEVER
17. ELECTRICAL LAYOUT COVER
18. BRAKE PEDAL
19. BUMPER
20. ACCELERATOR PEDAL
21. OUTER FILTER DETERGENT SOLUTION
22. STEERING WHEEL
23. BOTTOM PLATE
24. BRUSH BASE GROUP
25. TRACTION WHEELS



INTRODUCTORY COMMENT

Thank you for choosing our machine. This floor-cleaning machine is used for industrial and commercial cleaning and is able to clean any type of floor. During its forward movement, the action of the brush and detergent solution removes the dirt, which is picked up by the suction system, resulting in a dry surface.
The machine must be used only for this purpose. It gives the best performance if it is used correctly and properly. Therefore, we ask you to read this instruction booklet carefully whenever difficulties arise in the course of the machine's use. If needed, please contact our service department for advice and/or service.

GENERAL RULES

The rules below have to be followed carefully in order to avoid damage to the machine and injuries to the operator.
- Read the labels carefully on the machine. Do not cover them for any reason and replace them immediately if damaged.
- The machine must be used exclusively by authorized staff that has been instructed for its use.
- When using the machine, pay attention to other people, especially children.
- In case of danger, immediately use the emergency brake.
- To park the machine, take off the key and put on the parking brake.
- Do not mix different detergents to avoid harmful odors.
- Do not place any liquid containers onto the machine.
- The storage temperature has to be between -13°F and +131°F.
- The operating temperature should be between 32°F and 104°F.
- The humidity should be between 30 and 95%.
- Do not use the machine in an explosive atmosphere.
- Do not use the machine as a means of transportation.
- Do not use acidic solutions, which could damage the machine and/or injure people.
- Do not use the machine on surfaces covered with inflammable liquids or dusts (for example hydrocarbons, ashes or soot).
- In case of fire, use a powder fire-extinguisher. Do not use water.
- Watch out for shelves and/or scaffoldings, when operating the machine.
- Use the appropriate speed based on floor conditions (type of floor, dirtiness, etc).
- Do not use the machine on areas that have a higher gradient than the one stated on the number plate.
- The machine has to carry out simultaneously the operations of washing and drying. Different operations must be carried out in restricted areas prohibited to non-authorized personnel.
- Signal the areas of moist floors with suitable signs.
- If the machine does not work properly, check by conducting simple maintenance procedures. Otherwise, contact an authorized technical assistant for advice.
- Where parts are required, ask for ORIGINAL spare parts to the distributor or an authorized dealer.
- Use only ORIGINAL brushes.
- When cleaning and performing maintenance operations, disconnect the power supply plug from the machine.
- Do not wash the machine with corrosive material, direct water jets or high water pressure.
- Every 200 working hours, have the machine checked by an authorized service center.
- In order to avoid scales on the solution tank filter, do not fill the detergent solution hours before it is used.
- Before using the machine, check that all panels and coverings are in position as indicated in this use and maintenance catalog.
- Be sure the recovery tank is empty before lifting it.
- Restore all electrical connections after any maintenance operation.
- When your machine has to stop activity, provide the appropriate waste disposal for its materials, especially oils, battery and electronic components. Consider that the machine itself has been constructed by recyclable materials.

SYMBOLS


Symbol denoting the switch for the water opening and the signal lamp that the water is open.


Symbol denoting the functioning of the solution valve adjusting the flow of the detergent solution.



Indication of the maximum temperature of the detergent solution. It is placed near the charging hole of the solution tank.

Symbol denoting the selection switch of the operation mode manual/automatic.


Symbol denoting the push button and the signal lamp up/down brushes.

Symbol denoting the signal lamp of the starting of the brushes rotation.


Symbol denoting the push button to visualize on the display the brush pressure set.



Symbol denoting the functioning of the adjustment knob of the brush pressure.


Symbol denoting the push button and the signal lamp up/down of the squeegee.

Symbol denoting the switch of the vacuum motor.


Symbol denoting the charge level of the battery.

Symbol denoting the push button to visualize the hour meter on the display.


Symbol denoting the drive selector forwards/backwards.


Symbol denoting the selection switch of the operation speed.

Symbol denoting the signal lamp of the parking brake switched on.



Symbol denoting the lever position for the connection of the parking brake.


Symbol denoting the open book. Indicates that the operator has to read the manual before the use of the machine.

Warning symbol.
Read carefully the sections marked with this symbol, for the security of both the operator and the machine.

BEFORE USE

HANDLING OF THE PACKED MACHINE

The machine is supplied with suitable packing for fork lift truck handling.
The total weight is 783 lbs.
Packing dimensions:
Base: 71 in x 37 in
Height: 54 in

⚠ **ATTENTION:**
Do not place more than 2 packings on top of each other.

UNPACKING OF THE MACHINE

1. Remove the external packing.
2. Unscrew the brackets (1+2) that secure the machine to the pallet.



3. Move the machine backwards, as indicated in the figure, avoiding heavy contacts to mechanical parts.



BATTERY INSTALLATION AND SETTING OF THE BATTERY TYPE

The machine is equipped either with a battery in serial connection or elements of DIN-type assembled together and connected in series for a total of 36 Volts, placed in its appropriate compartment under the seat platform. It must be handled using suitable lifting equipment (due to weight, considering the type of battery chosen, and coupling system).
The battery must be in accordance with CEI 21-5 Norms.

⚠ **ATTENTION:**
CHECK THE SETTING OF THE CHECK CARD (see under paragraph "BATTERY CHARGE LEVEL INDICATOR").
In case of WET battery installation, it is necessary to set the battery check card. Please contact an authorized technical assistant.

⚠ **ATTENTION:**
Strictly follow manufacturer/distributor

BATTERY CHARGER

Make sure that the battery charger is suitable for the installed battery both for their capacities and for type (WET and equivalent).

In the plastic bag containing the use and maintenance you will find the coupling connector for the charger. It must be assembled onto the cables of your charger, following the instructions given by the manufacturer.

⚠ **ATTENTION:**
This operation must be carried out by qualified staff. A wrong or faulty cable connection can cause serious damage.

BATTERY RECHARGING

1. Plug the connector (3) of the battery charger into the battery connector (1) fixed on the steering column.
2. Proceed to recharging.



⚠ **ATTENTION:**



6. Open the bar of the side rubber (2) as shown in the figure.
7. Extract and carry the box by using its handles (3).



8. Empty the box into appropriate containers, in compliance with rules of liquid disposal.
9. Put the collection box back into its position up to the end seat.
10. Place the bar of the side rubber (2) into its position blocking it with the knob (1).

SUCTION FILTER CLEANING

1. Take off suction cover (4) after rotating the blocking levers (5).
2. Take off the filter (8) and its filter protection (6).
3. Clean all parts with a water jet, especially the inside surfaces and the filter bottom.
4. Carry out cleaning operations carefully.
5. Reassemble all parts.



BRUSH CLEANING

Disassemble the brush and clean them with a water jet (see "BRUSH DISASSEMBLY").

⚠ **ATTENTION:**

Carrying out brush disassembly operations with the electric supply on may cause injury.

SQUEEGEE CLEANING

Keep the squeegee clean for the best drying results. For cleaning it is necessary to:

1. Take off the squeegee hose (5) from the coupling.
2. Disassemble the squeegee (2) from its support (1) by rotating the lever (4) counter-clockwise, making slide the stud bolts (3) in the slots up to their release.
3. Clean with care the internal part of the squeegee inlet eliminating dirt residuals.
4. Clean with care the squeegee rubbers.
5. Reassemble all parts.



WEEKLY MAINTENANCE

REAR SQUEEGEE RUBBER CHECK

Check the wear of the squeegee rubber.
For the replacement, it is necessary to:

1. Lift the squeegee (see "STOP OF MACHINE AFTER CLEANING OPERATION").
2. Release the hook (1) of the rubber holder blade and take off the rubber.
3. Turn the rubber to a new side or replace it.

To reassemble the squeegees follow the directions above in reverse, inserting the rubber on the guides and blocking it with the rubber holder blade.



CHECK OF THE SIDE RUBBERS

With the brushes assembled, the side rubbers must touch the floor. If they are worn, they have to be replaced.
To replace the rubbers on both sides of the machine:

1. Unblock the bar of the side rubber after releasing the knob (1).
2. Open the bar of the side rubber (2) as shown in the figure.
3. Take off the fixing screws (3) of the rubber blade (4) and replace the rubber.
4. Reassemble all parts.





SQUEEGEE HOSE CLEANING

Weekly or in case of insufficient suction, check that the squeegee hose is not obstructed. To clean it, proceed as follows:

1. Take off the hose (1) from the squeegee coupling.
2. Wash the inside of the hose with a water jet.
3. To reassemble the hose follow the directions above in reverse.



CLEANING OF THE SOLUTION TANK AND OF THE OUTER FILTER

1. Bring the machine to an appropriate place to drain the detergent solution
2. Unscrew the solution tank cap (1).
3. Unscrew the cap of the exhaust filter (2) and take off the filter. Be careful not to lose the gasket of the cap.
4. Open the solution valve (see "FLOW ADJUSTMENT OF DETERGENT SOLUTION"), so that the detergent solution flows down into appropriate containers.
5. Rinse with a water jet the solution tank and the components of the filter.
6. Reassemble all parts.

NOTE: if needed it is possible to wash only the components of the outer solution filter as above-mentioned by closing the solution valve adjustment (see "FLOW ADJUSTMENT OF THE DETERGENT SOLUTION"), so that the detergent solution remains in the solution tank.



TWO-MONTH MAINTENANCE

FRONT SQUEEGEE RUBBER CHECK

Check the wear of the squeegee rubber and replace it if needed.
For the replacement:
1. Take off the squeegee (see under paragraph "SQUEEGEE CLEANING").
2. Unscrew the wing nuts in the front part of the squeegee.
3. Take off the rubber holder blade.
4. Replace the front rubber.
5. Reassemble all parts.

SIX-MONTH MAINTENANCE

CLEANING THE INNER FILTER SOLUTION TANK

Empty the solution tank; remove the fitting of the water outlet by taking off the two screws that fix it to the tank in the front part of the machine. Clean the inside filtrating part of the fitting from dirt. Pour some water into the tank to clean it. Reassemble the fitting onto the solution tank.

CHECK THE BRAKE

Check the braking efficiency of both rear wheels. Should the braking be insufficient, please contact an authorized technical assistant.

TROUBLESHOOTING GUIDE

⚠ **ATTENTION:**

If the machine is on, and the display and/or other functions are not activated, check the battery connection of the machine (see "CONNECTING BATTERY' AND SWITCHING ON THE MACHINE"). If the problem persists, please contact an authorized technical assistant.

THE VACUUM MOTOR DOES NOT WORK

1. Verify that the machine is on. If alarm signals appear, turn off the machine and restart it.
2. Check the charge level of the battery on the display (1).
3. Verify that the drying function is activated correctly (see "STARTING THE MACHINE").
4. Check that the recovery tank is not full.
5. Check that the float switch (2) in the recovery tank is assembled correctly.
6. For both in mode (MAN) as (AUTO), if the signal lamp (7) is on but the suction system does not work, it is necessary to rotate the recovery tank (see "ACCESS TO THE BATTERY COMPARTMENT"). Check the connection of the vacuum motor plug at the bottom of the tank.

If the problems persist, please contact an authorized technical assistant.





THE BRUSH MOTOR DOES NOT WORK

1. Verify that the machine is on. If alarm signals appear, turn off the machine and restart it.
2. Check the charge level of the battery on the display (1).
3. Verify that the function of washing with the brush is activated (see "STARTING THE MACHINE").
4. If the signal lamp (17) is on but the brush does not turn, please contact an authorized technical assistant

.If problems persist, please contact an authorized technical assistant.



THE TRACTION MOTOR DOES NOT WORK

1. Sit on the guiding place.
2. Verify that the machine is on. If alarm signals appear, turn off the machine and restart it.
3. Check the charge level of the battery on the display (1).
4. Check through the signal lamp (2) that the parking brake is not inserted.
(see "EMERGENCY-PARKING BRAKE").
5. Press the accelerator pedal placed on the right side to start the machine.

If problems persist, please contact an authorized technical assistant.



THE WATER DOES NOT COME DOWN ONTO THE BRUSHES OR IS INSUFFICIENT

1. Verify that machine is on.
2. Check the charge level of the battery on the display (1).
3. Verify that the function of washing with the brush is activated correctly (see "STARTING THE MACHINE").
4. Check that the solution valve is open (see "FLOW ADJUSTMENT OF DETERGENT SOLUTION").
5. If the signal lamp (16) is on but the detergent solution does not come down onto the brush, do the following:
   a. check the level of the liquid in the tank.
   b. check that the solution filter is clean (see "CLEANING THE SOLUTION TANK AND OF THE OUTER FILTER").
   c. check that the inner filter of the solution tank is clean (see under paragraph "CLEANING THE INNER FILTER SOLUTION TANK").

If the problem persists, please contact an authorized technical assistant.



THE MACHINE DOES NOT CLEAN PROPERLY

1. The brushes do not have suitable bristle dimension, contact an authorized technical assistant.
2. The brushes have worn bristles. Check the brush wear condition. If needed, replace them (the brushes have to be replaced when the bristles have reached a height of .60 in).
To replace the brushes, see instructions under "BRUSH DISASSEMBLY" and "BRUSH ASSEMBLY".
3. The detergent solution is insufficient: open more the solution valve (see "FLOW ADJUSTMENT OF DETERGENT SOLUTION").
4. Check that the liquid detergent is in the recommended percentage.
5. Increase the brush base pressure (see " BRUSH PRESSURE ADJUSTMENT").

Contact authorized technical assistance for advice.

THE SQUEEGEE DOES NOT DRY PROPERLY

1. Check that the suction function is on and that the recovery tank is not full.
2. Check that the squeegee rubbers are clean (see "SQUEEGEE CLEANING").
3. Check the height and the inclination of the squeegee (see "ADJUSTMENT OF THE SQUEEGEE").
4. Check that the suction and the squeegee hoses are correctly inserted in their proper seats on the recovery tank.
5. Clean the suction filter (see "SUCTION FILTER CLEANING").
6. Clean the squeegee hose ("SQUEEGEE HOSE CLEANING").
7. Replace the rubbers if worn out.

EXCESSIVE FOAM PRODUCTION

Check that low foam detergent has been used. Add small quantities of anti foam liquid into the recovery tank.
Please be aware that a bigger quantity of foam is produced when the floor is not very dirty. In this case please dilute detergent solution.

PROGRAMMED MAINTENANCE

INTERVENTION	DAILY	20 HOURS *	200 HOURS *	1000 HOURS *
RECOVERY TANK CLEANING	•			
SUCTION FILTER CLEANING	•			
SOLUTION TANK FILTER CLEANING		•		
BRUSH CLEANING	•			
BRUSH DISASSEMBLY AND CLEANING	•			
SQUEEGEE CLEANING	•			
FRONT SQUEEGEE RUBBER REPLACEMENT			•	
REAR SQUEEGEE RUBBER REPLACEMENT		•		
REPLACEMENT SIDE RUBBERS			•	
CHECK SQUEEGEE ADJUSTMENT		•		
SQUEEGEE HOSE CLEANING		•		
SOLUTION TANK CLEANING		•		
CHECK BATTERY ELECTROLYTE		•		
CHECKING THE BRAKE				•
TRACTION MOTOR CHECK				•
BRUSH MOTOR CHECK				•
VACUUM MOTOR CHECK				•
CHECK BRUSH BASE GROUP			•	
SCREW TIGHTENING				•

* The hours refer to the ones indicated on the display (see under paragraph"HOUR METER").

WARRANTY REGISTRATION FORM

Please provide additional information on Tornado equipment: *(Check choices below)*

- ☐ Automatic Scrubbers
- ☐ Propane Floor Machines
- ☐ High Speed Burnishers
- ☐ Carpet Extractors & Spotters
- ☐ Steam Cleaners
- ☐ Ride-on Equipment
- ☐ Sweepers
- ☐ Rotary Floor Machines
- ☐ Carpet Vacuums
- ☐ Wet/Dry Vacs
- ☐ Jumbo Vacs
- ☐ Pressure Washers

See complete product info at www.tornadovac.com

SELLING DEALER: (required)

_____

Please print clearly.

COMPANY/INSTITUTION

CONTACT NAME | TITLE

ADDRESS | CITY/STATE/ZIP CODE

PHONE | FAX

DATE OF PURCHASE | EMAIL

See white metal plate or sticker on unit for this information.

MACHINE TYPE/MODEL NUMBER:	MACHINE SERIAL NUMBER:
1.	1.
	2.

Facility Description (please circle all that apply)

1. School
2. Retail Store
3. Restaurant
4. Office Building
5. Contract Cleaning
6. Light Manufacturing
7. Heavy Manufacturing
8. College/University
9. Hospital
10. Nursing Home
11. Religious Institution
12. Airport
13. Warehouse
14. Apartment/Condo
15. Warehouse
16. Supermarket
17. U.S. Govt.
18. Other Govt.
19. Auto Service
20. Shopping Ctr.
21. Non-Profit
22. Other (specify) _____ _____

How did you first learn about Tornado cleaning and maintenance equipment?	In square feet *(meters)*	
	Total Hard Floor Area	Total Carpeted Area Square feet (square meters)
☐ Contacted by local dealer ☐ Previous experience with Tornado products ☐ Reputation/Recommendation ☐ Advertising ☐ Direct mail ☐ Internet ☐ Other _____	☐ 0-10,000 *(0-930)* ☐ 10-50,000 *(930-4,650)* ☐ 50-250,000 *(4,650-23,250)* ☐ Over 250,000 *(over 23,250)*	☐ 0-10,000 *(0-930)* ☐ 10-50,000 *(930-4,650)* ☐ 50-250,000 *(4,650-23,250)* ☐ Over 250,000 *(over 23,250)*

Damage or defect arising from abuse, neglect, or other misuse is excluded from this warranty. Other items may or may not apply based on your specific machine. If any defect occurs, the warranty is voided if service is attempted by non-Authorized Tornado Service Centers.

©2000 Tornado Industries. All rights reserved.

F2739

Tornado®

Today's Innovative Leader in Cleaning and Maintenance Equipment

Return to:
Tornado Industries
7401 W. Lawrence Avenue
Chicago, IL 60706
Fax: (708) 867-6968