BISSELL®

WE MEAN CLEAN

Earn Reward Points
register your new product today!
on back page

STEAM&sweep™ pet

USER'S GUIDE
46B4, 92L2 SERIES

2 Thank You

3 Safety Instructions

4 Product View

5 Assembly

6-8 Operations

9 Maintenance and Care

10 Troubleshooting

10 Replacement Parts

10 Additional Accessories

11 Warranty

12 Product Registration

12 Consumer Services

Thanks for buying a BISSELL Steam & Sweep™ Pet

We're glad you purchased a BISSELL Steam & Sweep™ Pet. Everything we know about floor care went into the design and construction of this complete, high-tech home cleaning system.

Your Steam & Sweep™ Pet is well made, and we back it with a limited two year warranty. We also stand behind it with a knowledgeable, dedicated Consumer Services department, so, should you ever have a problem, you'll receive fast, considerate assistance.

My great-grandfather invented the floor sweeper in 1876. Today, BISSELL is a global leader in the design, manufacture, and service of high quality homecare products like your Steam & Sweep™ Pet.

Thanks again, from all of us at BISSELL.



Mark J. Bissell
Chairman, President & CEO

IMPORTANT SAFETY INSTRUCTIONS

SAVE THESE INSTRUCTIONS

Commercial use of this unit will void the manufacturer's warranty.

When using an electrical appliance, basic precautions should be observed, including the following:

READ ALL INSTRUCTIONS BEFORE USING YOUR STEAM & SWEEP™ PET.

⚠ **WARNING: To reduce the risk of fire, electric shock, or injury:**

- Do not direct steam at people, animals, or at electrical outlets.
- Do not use outdoors or on wet surface.
- Unplug from outlet when not in use and before conducting maintenance or troubleshooting.
- Do not leave steam cleaner unattended.
- Do not leave the steam cleaner connected to an electrical outlet when not in use.
- Do not service steam cleaner when it is plugged in.
- Do not use with damaged cord or plug.
- Do not use steam cleaner if it has been dropped, damaged, left outdoors or dropped into water, return it to a service center.
- Do not handle steam cleaner with wet hands. Do not pull or carry by cord, use cord as a handle, close door on cord, pull cord around sharp corners or edges, or expose cord to heated surfaces.
- Do not unplug by pulling on cord.
- Do not use appliance in an enclosed space filled with vapor given off by oil-based paint, paint thinner, some moth proofing substances, flammable dust, or other explosive or toxic vapors.
- Do not allow to be used as a toy.
- Do not use on leather, wax polished furniture or floors, synthetic fabrics, velvet or other delicate, steam-sensitive materials.
- Do not immerse.
- Do not use for any purpose other than described in this User's Guide.
- Keep hair, loose clothing fingers, and all parts of the body away from moving parts.
- Use extra care when cleaning on stairs.
- Use only manufacturer's recommended attachments-use of attachments not provided or sold by BISSELL may cause fire, electric shock or injury.
- Never put descaling, aromatic, alcoholic or detergent products into the steam cleaner, as this may damage it or make it unsafe for use.
- Unplug by grasping the plug, not the cord.
- Close attention is necessary when used near children.
- Do not put any object into appliance openings, or restrict air flow.
- Do not use with any opening blocked.
- Do not pick up hot, burning or smoking objects such as cigarettes, matches or hot ashes.
- Do not pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in the presence of explosive liquids or vapor.
- Do not pick up toxic material (chlorine bleach, ammonia, drain cleaner, gasoline, etc.).

THIS APPLIANCE HAS A POLARIZED PLUG.

To reduce the risk of electric shock, this appliance has a po;arized plug (one blade is wider then the other) This plug will fit in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a proper outlet. Do not change the plug in any way.

This model is for household use only.

Product view

Assembly

Your Steam & Sweep™ Pet assembles quickly and easily. The only tool you will need for assembly is a Phillips head screwdriver.

Your Steam & Sweep™ Pet is packaged with the following items:

Handle Assembly

Lower Body with Water Purification System

Maneuverable Swivel Head

Removable Water Tank

1 large Phillips Head Screw

1 small Phillips Head Screw

2 Mop Pads



Attach handle to Steam & Sweep™ Pet

1. Attach lower body to maneuverable swivel head (If your Steam & Sweep™ Pet came with the swivel head already assembled to the body, you may skip this step).

2. Secure maneuverable swivel head with small Phillips head screw. Tighten until secure.

3. Slide handle assembly down into lower body until it will go no further.

4. Secure the handle by placing the large Phillips head screw through the screw opening in the lower body and into the rear of the handle assembly. Tighten with screwdriver until secure.

5. Slide water tank onto lower body by lining up vertical glides and gently sliding tank into place.

Steam & Sweep™ Pet assembly is now complete.

1.

2.



3.

4.

5.

Special Features

Removable water tank

The water tank is located on the back of the Steam & Sweep™ Pet. It can be refilled with water any time during use. Distilled or demineralized water is recommended in place of tap water.
Do not use chemicals with your Steam & Sweep™ Pet.

Water purification system

This filter removes minerals and other impurities from tap water, preventing water deposits from damaging your Steam & Sweep™ Pet. It should be replaced when the bright green grains turn blue. To maximize performance of the filter, distilled water should be used.

Ready light

The ready light will glow when water has been converted to steam and the Steam & Sweep™ Pet is ready to use.

Steam on demand trigger

Press to release steam.

Maneuverable swivel head

Allows you to pick up dust and small debris while steam cleaning your floor. The maneuverable swivel head gets into tight spaces and under cabinets.

Deluxe mop pads

Reusable microfiber mop pad is machine washable and safe for all hard floor surfaces.

Tip:

To prevent damage to the machine, do not attempt to use your Steam & Sweep™ Pet without water in the tank.