ORECK®

AirInstinct™ Air Purifier

User's Guide

Model: AIR75B

Important!
Read this manual carefully, and keep for future reference.

ENERGY STAR

This product earned the ENERGY STAR® by meeting strict energy efficiency guidelines set by the US EPA. US EPA does not endorse any manufacturer claims of healthier indoor air from the use of this product.

The energy efficiency of this ENERGY STAR® qualified model is measured based on a ratio between the model's CADR for dust and the electrical energy it consumes, or CADR/Watt.

Enjoy

Congratulations on your purchase of the Oreck AirInstinct™ Air Purifier. Use this manual to learn the features, operation and maintenance of the Oreck Air Purifier.

Welcome to our **Call. Click.** customer service program. To speak with an Oreck representative call:

Call

USA: **1•800•989•3535**
Canada: **1•888•676•7325**

Click

On the web, point and click at: **www.oreck.com** and click locate a store on the top right.

ORECK

Contents

Safety **4**

General Warnings 4

Placement Warnings 5

Features **6**

Operation **8**

Maintenance **9**

Cleaning and Filter Replacement Intervals . . . 10

Replacing the filters 11

Filter Reset Mode. 12

Forced Reset Mode 12

Cleaning the Air Sensor 13

Adjusting the Air Sensor 14

Troubleshooting **15**

Warranty **16**

General Warnings

IMPORTANT SAFETY INSTRUCTIONS

Cleaning the unit while it is plugged in may result in electric shock, electric spark and serious injury. Unplug the unit before cleaning or maintenance

WARNING: To reduce the risk of fire, electric shock or injury, read and understand this user guide before operating this appliance.

- Do not operate unit if cord or plug is damaged. Doing so can result in electric shock. Discard the damaged unit or take it to an authorized service facility for examination and/or repair. USA: 1•800•989•3535 Canada: 1•888•676•7325
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- Only use the air purifier as described in this manual.
- Do not handle the unit with wet hands. Thoroughly dry your hands before handling any part of the air purifier.
- Hair, loose clothing and body parts can get caught in the machine resulting in injury. Keep hair, loose clothing and body parts away from openings and moving parts.
- Do not unplug by pulling on the cord. Doing so may result in electrical spark or fire. Unplug the unit by grasping, and pulling the plug.
- Do not use an extension cord.
- Do not place the air purifier near sources of heat, such as: stove tops, ovens, radiators or computers.
- Unplug the appliance from the power supply before servicing.
- This equipment should be inspected frequently and the dirt that has collected should be removed regularly to prevent excessive accumulation that may result in flashover or fire.
- Do not use the air purifier outdoors or on wet surfaces.
- Do not use the air purifier in an enclosed space where flammable, combustible or explosive gases are present.

- Do not use in an area where toxic vapors, flammable dust or oxygen tanks are present. Check the location and make sure these elements are not present.
- Warning: Product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.
- Do not place open flames, including candles, directly in front of the air purifier.
- It is important to keep all objects away from the air intake grille.
- Place the air purifier on a flat, solid, stable surface. Never place the unit on soft surfaces such as a bed or sofa.
- Position the air purifier so that the dirty air is not drawn across your head or body while sitting or sleeping.
- Place the air purifier so the plug on the power cord easily reaches a standard electrical outlet for a polarized plug.
- Children should be supervised when product is in use. Do not allow children to play on or near the air purifier. Keep children's hair, loose clothing, and body parts away from/ out of the intake grille, vents, holes, or openings.
- This product is suitable for use with solid-state speed controls.

Note: To reduce the risk of electric shock this product has a polarized plug (one blade wider than the other). The plug will only fit in a polarized outlet only one way. If the plug does not fit properly, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet. Do not alter the plug in any way.



READ AND SAVE THESE INSTRUCTIONS

Features

1. **Display Panel:** Air purifier controls and indicator lights.
2. **Power Button:** Turns the purifier On and Off.
3. **AUTO Mode and Speed Button:** Auto Mode automatically adjusts the fan speed. Speed button manually sets the fan speed to low, medium or high.
4. **Check Filter Light:** Indicates the filters may need to be replaced.
5. **Air Indicator:** Visually displays either a blue, purple, or red light based on the level of particles detected by the Air Sensor.
6. **Timer Button:** Turns unit off after a predetermined period of time. Time settings are 1, 4 and 8 hours.
7. **Air Sensor:** Measures the level of particles passing through the sensor.
8. **Front Grille:** Air enters here for the first stage of cleaning.
9. **Handle:** Use handle to move the purifier.



10. **Exhaust Grille:** Directs the flow of air as it exits the unit.
11. **Power Cord:** Plug into the outlet to begin use.
12. **Pre-filter:** Filters large particles such as dust, hair and lint that pass through the filter.
13. **Odor Filter:** Reduces odors and VOC's from the air that passes through the filter.
14. **HEPA Filter:** Captures dust, allergens, pet dander, mold and smoke from the air that passes through the filter.



⚠ WARNING!

Cleaning the unit while it is plugged in may result in electric shock, electric spark and serious injury. Unplug the unit before cleaning or maintenance

Cleaning and Filter Replacement Intervals

Proper care and cleaning of the air purifier is critical to performance. The following chart shows the recommended cleaning intervals and method.

Part	Time	Method
Cabinet	As needed	Wipe with damp cloth first. If required, follow with mild, non-abrasive cleaner.
Air Inlet and Outlet	Every two months	Brush with soft brush. Do not allow dust to fall inside the purifier.
Air Sensor	Every two months	See page 13 for instructions.
Pre-Filter	Two to four weeks	Rinse thoroughly in warm water as needed. Let dry before reinstalling.
Odor Filter	1 year	*Replace
HEPA Filter	2 years	*Replace

*Filter life will vary by usage and environment.

Replacing the Filters

IMPORTANT: A lways remove the protective plastic packaging from the filter before installing the filter.

1. **Unplug** the air purifier.
2. **Open** the cover by gently pulling from the bottom corners.
3. **Press** the two hooks above the pre-filter, pull straight out of the cabinet. Remove the used odor filter and HEPA filter. Thoroughly rinse the pre-filter and let it air dry before placing it back in the cabinet. **Note: Do not use heated or compressed air as part of the drying process.**
4. **Remove** the plastic bag from the filters.
5. **Place** the filters back in the cabinet in the following order: HEPA filter, odor filter, and pre-filter. **Note: Insert odor filter into the pre-filter frame before inserting into the unit.**
6. **Replace** the cover by connecting at the top and securing at the bottom.











Filter Reset Mode

1. When the indicator light comes on, the odor, Hepa or both indicator lights will illuminate; indicating which filter needs to be replaced.
2. After installing a new or replacement filter, press and hold the reset button for approximately two seconds.



Forced Reset Mode

If you have replaced a filter before the filter replacement light is illuminated:

1. Press and hold the reset button for 2 seconds.
2. Push the reset button to select the desired filter to forcibly reset. Push once for odor filter and twice for the Hepa filter.
3. To complete forced reset, press and hold the reset button for approximately 2 seconds.

   If 10 seconds have passed in the forced reset mode, the forced reset mode is cancelled.

*Filter life will vary by usage and environment.



Cleaning the Air Sensor

⚠ WARNING!

Cleaning the unit while it is plugged in may result in electric shock, electric spark and serious injury. Unplug the unit before cleaning or maintenance

1. **Open** the air sensor cover on the side of the product.



2. **Clean** the air inlet, outlet vents, and air sensor.



3. **Wet** a cotton swab lightly and clean the lens, dust inlet, and dust outlet. After cleaning, use a dry cotton swab to remove any moisture.



Note: Without regular cleaning, the sensor will decline in performance.

Adjusting the Air Sensor

The purifier is shipped with the Air Sensor set to standard sensitivity. Adjust the sensitivity of the sensor if you want the air purifier to adjust its fan setting in Auto Mode to more or less frequently.

To adjust the sensitivity of Air Sensor:

1. **Turn** the power On.
2. **Press** and hold the Auto/Speed button for two seconds.
3. The speed indicator blinks according to the current sensitivity of the air sensor.
4. **Press** the Auto/Speed button for the desired sensitivity.

Low	Medium	High
Sensitive	Standard	Insensitive



5. **Press** and hold the Auto/Speed button for two seconds to set the sensor.

   Note: If ten seconds have passed while in the setting mode the new setting will automatically be set.

Trouble-shooting

Service problems that appear to be major can often be solved easily. You can be your own troubleshooter by reviewing, this guide.

All other servicing should be done by an Oreck authorized service center.

Problem	Check	Solution
Unit does not turn ON.	• Power Cord • Cover	• Plug in power cord. • Make sure that the cover is securely closed. • Check electrical outlet.
No air is blowing.	• Power Cord • Is the power On?	• Plug in power cord. • Press and hold the POWER button to turn On.
Airflow speed is weak.	• Filters	• Check the filters. Replace if necessary. • Were the plastic bags removed from filters?
Color of Mood Light is always the same.	• Purple or Red • Blue	• Adjust the sensitivity of the air sensor to less sensitive or standard. • Adjust the sensitivity of the air sensor to more sensitive or standard.
Unit does not capture particles.	• Filters	• Check the filters. Replace if necessary. • Unit may be damaged Contact Oreck for service.
Unit still does not operate properly.	Review all of the above	Contact Oreck for service.

Warranty

ORECK MANUFACTURING COMPANY: (Oreck Manufacturing Company gives you the following limited warranty for this product only if it was originally puchased by you for residential use, not for resale, from Oreck or an Oreck Authorized Retail Dealer.)

Oreck will repair or replace, free of charge, to the original purchaser, any part that is found to be defective in material or workmanship within three (3) years following the date of purchase for all residential models. NOTE: If the unit is used commercially, a one (1) year overall warranty applies.

This limited warranty does not cover the replacement of expendable or consumable parts such as filters, cartridges, and other parts subject to normal wear unless they are defective in material or workmanship.

This limited warranty does not apply to any part subjected to accident, abuse, commercial use, alteration, misuse, damage caused by act of God, the use of voltages other than on the data plate of this product or service of this product by other than Oreck or a participating Factory Authorized Service Center.

Oreck does not authorize any person or representative to assume or grant any other warranty obligation with the sale of this product.

Oreck's limited warranty is valid only if you retain proof of purchase from Oreck or an Oreck Authorized Retail Dealer for this product. If you purchase this product from any other source, your purchase is "AS IS," which means Oreck grants you no warranty, and that you, not Oreck, assume the entire risk of the quality and performance of this product, including the entire cost of any necessary servicing or repairs of any defects.

Oreck's liability for damages to you for any costs whatsoever arising out of this statement of limited warranty shall be limited to the amount paid for this product at the time of original purchase, and Oreck shall not be liable for any direct, indirect, consequential or incidental damages arising out of the use or inability to use this product. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

ALL EXPRESS AND IMPLIED WARRANTIES OTHER THAN THE LIMITED WARRANTY SET FORTH ABOVE, FOR THIS PRODUCT, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY DENIED.

If there is an issue with your air purifier that you believe is covered by this warranty, contact Oreck customer service at 1-800-989-3535. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

ORECK

© 2011 Oreck Holdings, LLC.

All rights reserved. All marks, text, logo's, product configurations and registered trademarks are owned and used under the authority of Oreck Holdings, LLC.

22103-02 12/11 ECN # R-10883