

OPERATING INSTRUCTIONS

1. Plug in to a standard outlet with the correct voltage and amperage for the unit.
2. Place the dryer in the desired operating position.
3. Set the switch at the desired speed: low or high.
4. Check for proper operation before leaving the unit unattended.
Do not move or carry the dryer when it is running.


5 AMP Resettable Circuit Breaker

The Downdraft™ Fan features a 5 amp circuit breaker that will "trip" if more than 5 amps of electrical current is drawn through the cord.

Operating Positions

The Downdraft™ Fan is designed to operate in multiple positions for any type of drying.

1. **Face Down** – Set the Downdraft™ Fan on the four caster wheels to direct air straight down. Turn each caster to a 45° angle to the housing for best airflow.
2. **Tilt Back** – Tilt the Downdraft™ Fan backward on the four curved molded legs at an angle to direct air for elevated drying.
3. **Upright** – Set the Downdraft™ Fan square with the handle on the top to direct air across a room.
4. **Tilt Forward** – Tilt the Downdraft™ Fan forward on the "standing legs" at an angle to direct airflow along the flow in front of the dryer.
5. **Stack for Storage** – the Downdraft™ Fan interlock and stack for easy storage and transport.



MAINTENANCE/TROUBLE SHOOTING

Periodic Maintenance

1. Check power cord for any breaks, separations or cuts.
2. Make sure the ground pin or grounding prong is intact or the machine will be unsafe to operate.

Trouble Shooting (if the dryer will not run)

1. Check electrical cord; is it firmly seated in wall outlet
2. Check if dryer circuit breaker is tripped, reset if necessary.
3. Check to see if building circuit breaker is tripped. If circuit is overloaded, move cord to a different outlet.
4. If using an extension cord, make sure it is in good condition, proper gauge and firmly connected.



Operations & Maintenance Manual

For Commercial Use Only

TORNADO INDUSTRIES
7401 W. LAWRENCE AVENUE
CHICAGO, IL 60706
(708) 867-5100 FAX (708) 867-6968
www.tornadovac.com



Model Windshear™ Downdraft

MODEL NO.
 98784 (115v) & 98785 (230v)

Form No. L 9701

©2007 Tacony Inc. All rights reserved.

NOTES

Write your machine serial number here:_____

This instruction book covers:

MODEL NO.	98784	98785
VOLTS	115	230
SERIES	F	F

ALL SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE.

SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

When using an electrical appliance, basic precautions should always be followed.

WARNING- To reduce the risk of fire, electric shock or injury:

Use only as described in this manual. Use only manufacturer’s recommended components and attachments.

Use only indoors. Do not use outdoors or expose to rain.

Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to your Authorized dealer.

Do no pull or carry by cord, use cord as a handle, close door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.

Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.

- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, hair and anything that may reduce air flow.
- Turn off all controls before unplugging.
- Do not attempt to service the unit while appliance is plugged in.
- Appliance may cause a fire when operating near flammable vapors or materials. Do not operate this machine near flammable fluids, dust or vapors.
- Connect to a properly grounded outlet.
- Do not use with any solid state speed control device.
- This unit is thermally protected.




WARNING
Do not stack dryers more than 4 (four) units high for transport, 5 (five) units high for storage.

GROUNDING INSTRUCTIONS

This appliance must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This appliance is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

*This appliance is for use on a nominal 120 volt circuit and has a ground plug (see illustration, right). Make sure that the appliance is connected to an outlet having the same configuration as the plug. No adaptor should be used with this appliance. **WARNING** - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the appliance – if it will not fit the outlet, have a proper outlet installed by a qualified electrician.



*This applies only to North America. Most other countries use 230V circuit.
**This applies only to North America. The 230v model is designed to operate on a 230/50 Hz electrical connection. Make sure the electrical outlet is grounded and all safety precautions are taken.*

FOR BEST PERFORMANCE

- Keep machine clean and in good operating condition.
- Have machine checked periodically by your Authorized Dealer.
- Use only authorized service centers for parts or service.
- Store machine carefully in dry area.
- For optimum drying performance and safety, study and follow your operators manual.

SAVE THESE INSTRUCTIONS